



RELEASED
18.06.12
M.HL.

PPP

Part Number

Description

Box Part Number Dimension

Other Packaging

Logo Decals

Packaging Instructions and Decal Placement

D350-689-017

Put foam in bottom of box. Place hardware, kit and paperwork in box. Put more foam to prevent movement. Close the box. Apply Dart tape. Apply label D2729-3 as per instructions in QSI 014.

D2729-4

N/A

D2729-3

Dart Aerospace Ltd.
1270 Aberdeen Street
Hawkesbury, ON K6A 1K7
CANADA
TEL.: 1 613 632-5200

SHOULDER HARNESS

P/N: D350-689-017 CHG001

S/N: SXXXXXX

Revision: B
Date: 18.06.07

DAS
16
9-89
18.06.12